

ODP 20-4 2,000 Lb. Four Drum Puller

Pulling Control

The following instructions explain how to properly set up the unit when it is to be used as a puller and have a pulling rope UNDER TENSION. Use of these instructions assumes that all controls are at the same setting when the pulled previously stopped.

1. Begin to slightly actuate the joystick to take up
2. Release the brake
3. Actuate the joystick to take up as desired (if reel does not begin to move, slightly increase the Hydraulic Pressure Control until it does.

Level wind

This unit is equipped with an automatic diamond lead screw level wind system. No manual operation of the unit is required. Make sure shaft is properly pinned and lubricated prior to operation.

IF MACHINE IS TO BE USED FOR FIBRE OPTIC INSTALLATION, REFER TO THE CABLE MANUFACTURER FOR PROPER TENSIONING TECHNIQUES. FAILURE TO CONSULT MANUFACTURER MAY DAMAGE CABLE AND VOID WARRANTY.



"Rugged Dependability."

© COPYRIGHT 2016 HOGG & DAVIS, INC

