

**ODP40-4 HRC XS  
High Rope Capacity  
4,000 Lb Four Drum Puller**

***Pulling Control***

The following instructions explain how to properly set up the unit when it is to be used as a puller and have a pulling rope UNDER TENSION. Use of these instructions assumes that all controls are at the same setting when the pulled previously stopped.

1. Set brake to the off position.
2. Begin to slightly actuate the joystick to take up.
3. Release the brake.
4. Actuate the joystick to take up as desired. (if reel does not begin to move, slightly increase the Hydraulic Pressure Control until it does.)

***Level wind***

This unit is equipped with individual hydraulic level wind arms. Operation is by individual switch to corresponding reel.

**IF MACHINE IS TO BE USED FOR FIBRE OPTIC INSTALLATION, REFER TO THE CABLE MANUFACTURER FOR PROPER TENSIONING TECHNIQUES. FAILURE TO CONSULT MANUFACTURER MAY DAMAGE CABLE AND VOID WARRANTY.**