

**ODP 40 XS  
4,000 Lb Drum Puller**

***Rope Payout Procedure (Free Wheel)***

When beginning the rope payout feature, be sure that the engine is turned off. Ensure that all tension is removed from the pulling rope before attempting to remove drive pin.

Adjust reel brake to provide tension to the reel of rope. Remove the drive pin from the sprocket drive and place in the provided storage sleeve. Begin to pull rope through the blocks while continuing to adjust the over spin brake. When the rope install is completed, insert the drive pin the sprocket drive. Manual rotation of the rope reel may be needed to properly install drive pin.

Refer to the performance chart for proper hydraulic pressure as it directly relates to conductor tension. ***This chart is located on the control panel of the unit.***

***\*\*\*These instructions assume that the operator has set the proper drive pin for the reel to be pulled in. All other reels are to be disengaged with the over spin brake fully applied.***